

KamperAid™ - Mounting Instructions

Mounting Steps

- Position on frame
- Mark hole with pencil for mounting
- Drill $\frac{1}{4}$ " holes
- Using a ratchet tighten the self tapping $\frac{5}{16}$ " bolts into frame
- Tighten Flange Mount base to swing jack mount w/ $\frac{5}{16}$ " bolts and Spacers.

